



Installation Manual




Components list



Pre-installation


TOOLS REQUIRED



HARDWARE INCLUDED


A (x3) Ø10(x3) M8x90(x3)	B (x1) (x1)	C (x1) ST5x26(x1)
D (x1) ST5x6(x2)	E ST4.8x50(x4) (x2)	F (x3) ST6x25(x12)
G (x1) Ø8(x4) ST4.2x32(x4)	H (x3)	I (x3)

Installation



1



A



Installation

2

(x3)





3

H






A



Installation

4


F




Installation

5


E



1



2




6

B






C



Installation


7

G





1

2





3




Installation

8


C




1



2




3



Installation

9

B



Installation

10

- C 
- 
- D 
- 

