



Installation Manual




Components list



Pre-installation


TOOLS REQUIRED



HARDWARE INCLUDED


A Ø10 (x3) (x3) M8x90(x3)	B (x1)	C (x1) M5x26 (x1) (x1)
D (x1) M5x6(x2)	E (x3) M6X25(x12)	F (x1) (x1) Ø8(x4) ST4.2X32(x4)
G (x3)	H (x2) M 10x55 (x4) bolts for 35-40mm door M10x60 (x 4) bolts for 40-45mm door ST4.8X50 (x4)	(x4)

Installation




1

A



Installation

2





3

G






A



Installation

4


E



Installation


5

H



6

H




Installation

7

B





C




8


F




1




2



3







4



Installation

9


C



Installation

10

B




Installation

11


C




D




1



2



3



4

