



Installation Manual




Components list



Pre-installation


TOOLS REQUIRED



HARDWARE INCLUDED


A Ø10 (x3) Ø8 (x3) M8x90(x3) (x1) (x1)	B (x1)	C (x1) M5x26 (x1) (x1)
D (x1) M5x6(x2)	E (x3) M6X25(x12)	F (x1) (x1) Ø8(x4) ST4.2X32(x4)
G (x3)	H (x2) M 10x55 (x4) bolts for 35-40mm door M10x60 (x4) bolts for 40-45mm door ST4.8X50 (x4)	(x1)

Installation




1

A



Installation

2





3

G





A




Installation

4

E



2




(x3)

Installation


5

H



6

H




Installation

7

B








C



8


F



Installation

9








C



Installation

10

B





Installation

11


C




D




1



2



3



4

